MUSTANG
MOTORCYCLE SEATS

MOUNTING SUGGESTIONS

Harley-Davidson® Softail 2000-2006
Solo and Passenger Seats

Hardware:	Solo:	Passenger seat:
	Side Brackets x2	Stock rear bracket
	Side bolt/washer x2	(or Mustang part
	1/4"-20x3/4" bolts x2	78033)
	1/4"-20x1/2" screw x2	stock fender screw

Tools needed: Phillips screwdriver
7/16" wrench or nutdriver

These seats will install on the following motorcycles. If your motorcycle is not listed, please contact Mustang for fitment.

- FLST Heritage 2006
- FLSTC Heritage Classic 2000-2006
- FLSTF Fat Boy 2000-2006 and FLSTFSE 2005
- FXST Softail 2000-2005
- FXSTS Springer 2000-2005

Removal of stock seat:



One-piece stock seat:

1. Remove the two large Allen mounting bolts from each side of the seat.

2. Remove the rear 1/4" fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will b used to attach your new Mustang seat.

3. Slide the seat up and back to disengage the front bracket and remove the seat.

4. Remove the stock bracket from the rear of the seat.

5. If the stock seat was mounted into smaller mounts screwed into the frame, remove these before mounting the Mustang solo.

Installation of Mustang seat:

Solo alone:

1. Insert the solo's nose tab into the frame mount behind the tank.
2. Align the side brackets with the side frame mounts and install the two large chrome side bolts and washers. Tighten securely.

   Note: the angles of the steel pan may need to be adjusted slightly to fit your specific bike.

Solo and passenger seat:

1. Attach the stock rear bracket to the back of the Mustang passenger seat.

2. Remove the two 1/4"-20x1/2" fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will be used to attach your new Mustang seat.

3. Insert the solo's nose tab into the frame mount behind the tank.

4. **Optional:** align the side brackets with the side frame mount and re-install the two large Allen bolts. This is not required when installing with the passenger seat attached. These two brackets can be removed from the solo if desired.

5. Align the stock rear bracket on the passenger seat with the rear mount in fender and secure with stock screw.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 8:30 - 5:00 Eastern or send an e-mail to tech@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 75084, 75085, 75086, 75087, 75094, 75095, 75096, 75097, 76187, 76188, 76800, 76801, 76802, 76803, 76804, 76805, 76806, 76807, 76885, 79120, 79121, 79130, 79131, 79258, 79259, 79278, 79279, 79714, 79715, 79716, 79717, 79750, 79751, 79752, 79753



Products made by Mustang Motorcycle Products, LLC are warranted for one year against defects in material and workmanship. Mustang must first be notified of any apparent defect. A return authorization will be issued. Carefully pack the product and return prepaid. Upon receipt, Mustang will make a fair, prompt decision regarding repair or replacement. Incidental and consequential damages arising from or in connection with the installation or use of a Mustang product are not covered by this warranty. An original purchase receipt must be provided to obtain a warranty repair or replacement.