Installation Instructions

For part #127052 Street Glide / Road King LP6 Headlight Mounting Bracket

Kit Contains:

1- LP6 Adapter Mounting Bracket 127052

1- 6/32x5/8” long Machine Screw

Thanks for purchasing our Street Glide / Road King LP6 Headlight Bracket. This kit consists of 2 basic parts.

1. The main bracket which utilizes all the factory holes and screws.
2. A simple 6/32 screw that attaches your factory headlight bezel back on.

---

1. First, Make sure you have the bracket as shown below, the 6/32 screw, approved A10 Moto Wire Harness and your factory trim ring which will be re applied after light is installed.

2. Remove your factory light trim ring. Remove your factory light and bracket saving the screws that attached “Outer” light ring to your fairing.

3. Unplug your factory light and set it aside.

4. Open your LP6 Light and locate the Baja Designs Factory hardware bag.

5. Using the 1/4x20 bolts supplied, attach your LP6 light to your new Bracket #127052.

6. Plug in the A10 Moto LP6 plug into the back of light and set the entire light assemble inside your fairing.

7. At this point check for light level. Ideal setting is 87.5 Degrees when bike is level on ground (Not on stand)

8 You can install screws and check for light level first before fully tightening LP6. Once level is achieved, Pull the Assembly back out and fully tighten the 4 - bolts using 7/16 wrench.

9. Now you are ready to install the trim ring. Locate the spring on the inside top portion of your light bezel trim ring. With the small 6/32 Phillip pan head screw in your hand, insert the trim ring so that the spring is positioned at About 11:00 and rotate clock wise or to the right until the spring catches the hook. Then insert the screw under The trim ring locating the threaded hole. DO NOT Over tighten this screw, this can cause trim ring to crush. Just Tighten this up snug.





A10 Moto	**Phone: 714-534-6700**
Part# **127052**	Rev **B**
Street Glide / Road King Headlight Bracket	
File: Installation_ Instructions 127052 Install	

LP6 Fits snug inside
our Bracket 127052





Final Look with Trim Ring Installed

Thanks for your Support

A10 MOTO

follow us
@a10_moto

We are always looking
for industry reps and fans.

Create a video of your install
and post it on YouTube.